KitchenAid® COOKTOP PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02

(Black) (Pure White) (Pure Biscuit) (S.Steel)

30" FREE STANDING
ELECTRIC OVEN
CONVECTION



Illus. No.	Part No.	DESCRIPTION
1		Literaturre Parts
	9762035	Installation Instructiions
	9762265	Use & Care Guide
	9760713	Tech Sheet
	9757680	Anti−Tip Instruct.
	3191638	Safe Cooking Tips
	9759133	Safe Cooking Tips (French)
	9757645	Guide, Easy Set
2	9761593	Central, Appliance
3	4454023	Bracket, Mounting
4		Cooktop
	9759748BB	Biscuit
	9759748WW	White
	9759748BL	Black
	9759748SS	S.Steel
5	4453764	Clip, Ceran (2)

Illus. No.	Part No.	DESCRIPTION
6		Trim−CkTop, SI
	9756700WH	White LH
	9756700BT	Biscuit LH
	9756700BL	Black LH
	9756700SS	S.Steel LH
	9756701WH	White RH
	9756701BT	Biscuit RH
	9756701BL	Black RH
	9756701SS	S.Steel RH
7	9756450	Gasket
9		Support
	9757686	L.Hand
	9757687	R.Hand
10	9756821	Support, Wiring
11	4449809	Screw (2)
12		Element, Surface
	8203525	1800/1000W
	8523696	1800W RR
	4453909	2500/1200W (2)
13	9757800	Bracket, Front Support
14	4454019	Cover, Backsplash Rear

Illus. No.	Part No.	DESCRIPTION
15		Backsplash
	9759454BL	Black
	9759454BT	Biscuit
	9759454WH	White
	9759886SS	S.Steel
		Gasket
	9757767BL	Black
	9757767GY	Gray
16	9759944	Thrmstat, 60c SPST
17	9758799	Bracket, Ind. Lamp
18	3196160	Screw (2)
19	9759094	Spring, Locator
20	9759963	Bracket, Rear Sprt
21		Rail, Element (2)
	8285962	Side (3)
	9757825	Center (1)
22	246119	Screw
23	9761724	Cover, Cktp Rear
24	8523739	Indicator Lamp, Hot Surface
25	3196537	Screw
26	3196178	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02

(Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
	4453840WH	White
	4453840BT	Biscuit
	4453840BL	Black
	4453840SS	S.Steel
2		Membrane Switch
	9756595WH	White
	9756595BT	Biscuit
	9756595BL	Black
	9756595ES	Etched Stainless
3	9762812	Control, Interface
4	9757119	Bracket, Console
5	3196068	Lens, Ind. (2)
6	9757787	Bracket, User Interface
7	311865	Screw
8		Endcap
	4453880BT	Biscuit LH
	4453880WH	White LH
	4453880BL	Black LH
	4453880CM	S.Steel LH
	4453884BT	Biscuit RH
	4453884WH	White RH
	4453884BL	Black RH
	4453884CM	S.Steel RH
9		Knob
	9756941	White
	9756942	Biscuit
	9756943	Black
	9756944	Cashmere Metal
11		Switch, Infinite
	9760690	RF
	9760691	LF,RR,LR
12	9757778	Bushing
13	9759827	Insert, Membrane
14	3196537	Screw
16	3196172	Screw

OVEN PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02

(Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02
(Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Side (Right Hand)
	9756619WH	White
	9756619BT	Biscuit
	9756619BL	Black
	9756619SS	S.Steel
		(Left Hand)
	9756620WH	White
	9756620BT	Biscuit
	9756620BL	Black
	9756620SS	S.Steel
2	3400832	Screw
3		Hinge Receiver
	4455605	Left Hand
	4455606	Right Hand
4	4448520	Bumper, Door
5	9757461	Bracket,Side Panel
6	9757811	Brace, Side Panel
7	8303099	Top Chassis
8	4449809	Screw
9	4452158	Tube, Vent
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light
13	9757732	Shield, Heat
14	9759060	Frame, Front
15	4455382	Gasket, Door
16	4453951	Deflector, Vent Bottom
17	4452152	Bracket, Mounting
18	9757685	Guide,Side Pnl (2)
19	4451478	Support, Insulation
20		Body, Side
	9760723PB	Black
	9760723PC	Biscuit
	9760723PW	White
21	3196537	Screw
22	9760888	Latch, Motorized
23	341196	Thermostat SPST (205)
24	9759890	Clip, Side Panel
25	4455641	Side, Chassis (R.H. & L.H.)
26	9759761	Back, Chassis
27		Liner, Oven (Not serviceable)
28	9759945	Cover, Rear Standoff
29	4455636	Sensor
30	9756454	Bracket, GOC
31	9756452	Slide. GOC
32	3196160	Screw
33	9757717	Insulation, Bottom Vent
34	4449743	Screw
35	3196176	Screw
36	4449040	Screw
37	9759242	Thermostat (TOD) Manager, 130c (Temp.) SPST
38	4449154	Screw
43	9759713	Base, Chassis
49	4448933	Retainer, Gasket
50	4451747	Cover, Back
54		Vent, Bottom Upper
	9756481WH	White
	9756481BT	Biscuit
	9756481BL	Black
	9756481SS	S.Steel
55		Trim, Btm Vent
	9756485WH	White
	9756485BT	Biscuit
	9756485BL	Black
	9756485SS	S.Steel

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

9756817	Insulation, Wrap
9756470	Insulation, Back

DOOR AND DRAWER PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02

(Black) (Pure White) (Pure Biscuit) (S.Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02
(Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
1		Nameplate
	9757730BL	Black
	9757730BT	Biscuit
	9757730WH	White
2	4453107	Nut
4	4457132	Retainer, Glass
5		Glass, Door Front
	9757102BL	Black
	9757102WH	White
	9757102BT	Biscuit
	9757102SS	S.Steel
6	9760887	Cover, Terminal
7	3196176	Screw
8		Handle, Door
	9756833BL	Black
	9756833WH	White
	9756833BT	Biscuit
	9756833OG	S.Steel
9	8302094	Bracket, Central
10		Hinge, Door
	9760579	R.Side (Orange)
	9760580	L.Side (Orange)
11	9761935	Foot, Rear
12	8302092	Bracket, Side
13	8274149	Sensor
14	8054056	Element, Warming
15	9757706	Glass, Inner
16	4457114	Shield, Heat Btm
17	4449263	Glass, Inner (2)
18	4451722	Insulation, Door
19	9759413	Liner, Door
20	9757805	Drawer Assy
21	3196037	Foot, Front
22	9760590	Panel, Drawer
23	9758676	Support, Element
24		Front, Drawer
	4453799WH	White
	4453799BL	Black
	4453799BT	Biscuit
	4453799SS	S.Steel
25		Bracket, Handle
	4457231	R.Hand
	4457232	L.Hand
26		Handle, Drawer
	9756952WH	White
	9756952BT	Biscuit
	9756952BL	Black
	9756952CM	S.Steel
27	8533988	Screw
28	4449809	Screw
29		Side, Base
	9759953	R.Side
	9759954	L.Side
30	4449743	Screw
31	3196537	Screw
32		Guide, Roller
	4453719	R.Hand
	4453718	L.Hand
33	9757707	Shield, Heat Top

INTERNAL OVEN PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02
(Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	8301514	Element, Broil
2	4449154	Screw
3	4457277	Grill, Broiler
4	4457276	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
8	4448948	Probe, Meat
9	4452157	Element, Convect.
10	9756690	Cover, Fan
11	4455037	Tray, Hidden Bake
12	4450039	Cover, Bake Tray
13	4451583	Motor, Convection
14	4452227	Nut
15	4452226	Blade, Fan
16	4451355	Jack, Meat Probe
17	4448882	Lock Washer
18	4448881	Hex Nut
19	9759681	Rack, Half
20	8274022	Rack, Insert

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02
(Black) (Pure White) (Pure Biscuit) (S.Steel)



Illus. No.	Part No.	DESCRIPTION
1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent Top
3		Blower
	9759320	60mm
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	9759938	Bracket, Term.Box

Illus. No.	Part No.	DESCRIPTION
7	4449809	Screw
8	9757404	Box, Terminal
9	9759721	Insulator,Term Box
10	9761958	Block, Terminal
11	4449868	Block, Terminal
12	9757405	Cover, Term Box
13	9757118BL	Vent, (Control Panel)

Illus. No.	Part No.	DESCRIPTION
14	9757829	Bracket, Transfrmr
15	9756551	Transformer
16	4449040	Screw
17	3400080	Screw
18	3196160	Screw
19	4450038	Screw
20	4455352	Bracket, Blower
21	9759884	Insulation

OPTIONAL PARTS

For Models: KERK807PBL02, KERK807PWW02, KERK807PBB02, KERK807PSS02
(Black) (Pure White) (Pure Biscuit) (S.Steel)

Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
	261869	Cord Brown
	72032	Black
PAINT, SPRAY		
	350930	White
	261900	Citrine White
	830864	Black
ADHESIVE		
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
SPLICING WIRES−−25FT. LENGTH		
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
WIRING HARNESS PARTS		
	9762523	Harness, Wire (Main)
	9760693	Harness, Wire (Switch, Elec)
	9756554	Harness, Wire
	9759715	Conduit
	313660	Clip, Ground Wire
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4452222	Spacer, Harness
	3400015	Screw, Ground
Miscellaneous		
	814381	Hinge Pin Kit
	9759899	Bakeware
	4448950	Screw, Install (4)
	9782676	Anit−Tip Assy